



# Thermal Image Scope PANTHER 2.0 Series

User Manual V5.5.64 202304



Contact Us

## Table of Contents

Chapter 1 Overview .....	1
1.1 Device Description .....	1
1.2 Main Function .....	1
1.3 Appearance .....	1
Chapter 2 Preparation .....	4
2.1 Cable Connection .....	4
2.2 Install Battery .....	4
2.2.1 Battery Instruction .....	4
2.2.2 Battery Installation .....	4
2.3 Install Rail .....	6
2.4 Power On/Off .....	6
2.5 Menu Description .....	7
2.5.1 Main Menu .....	7
2.5.2 Quick Menu .....	8
2.6 Client Software Connection .....	8
2.7 Firmware Status .....	9
2.7.1 Check Firmware Status .....	9
2.7.2 Upgrade Device .....	10
2.8 Zeroing .....	11
Chapter 3 Image Settings .....	12
3.1 Adjust Diopter .....	12
3.2 Adjust Focus .....	12
3.3 Adjust Image Brightness .....	13
3.4 Adjust Contrast .....	13
3.5 Adjust Tone .....	13
3.6 Adjust Sharpness .....	13
3.7 Select Scene Mode .....	14
3.8 Set Palettes .....	14
3.9 Correct Defective Pixel .....	16
3.10 Flat Field Correction .....	17

---

3.11 Set Picture in Picture Mode .....	17
3.12 Set Zoom Mode.....	17
<b>Chapter 4 Zeroing .....</b>	<b>19</b>
4.1 Select Zeroing Profile .....	19
4.2 Correct Reticle .....	19
4.3 Set Reticle Style .....	21
<b>Chapter 5 Measure Distance .....</b>	<b>22</b>
<b>Chapter 6 General Settings.....</b>	<b>23</b>
6.1 Set OSD .....	23
6.2 Set Brand Logo .....	23
6.3 Adjust Display Brightness .....	23
6.4 Burning Prevention .....	24
6.5 Capture and Video .....	24
6.5.1 Capture Picture .....	24
6.5.2 Record Video .....	24
6.5.3 Set Audio .....	25
6.5.4 Prerecord Video .....	25
6.6 Hot Tracking.....	25
6.7 Export Files .....	26
6.7.1 Export Files via HIKMICRO Sight.....	26
6.7.2 Export Files via PC .....	27
<b>Chapter 7 System Settings.....</b>	<b>29</b>
7.1 Adjust Date .....	29
7.2 Adjust Time .....	29
7.3 Set Unit .....	29
7.4 Set Language.....	29
7.5 View Device Information .....	30
7.6 Restore Device .....	30
<b>Chapter 8 Frequently Asked Questions .....</b>	<b>31</b>
8.1 Why is the monitor off? .....	31
8.2 The image is not clear, how to adjust it? .....	31

---

## Thermal Image Scope User Manual

---

8.3 Capturing or recording fails. What's the problem? .....	31
8.4 Why the PC cannot identify the device? .....	31
<b>Chapter 9 Appendix .....</b>	<b>32</b>
9.1 Device Command .....	32
9.2 Device Communication Matrix .....	32
<b>Safety Instruction .....</b>	<b>33</b>
<b>Legal Information .....</b>	<b>36</b>
<b>Regulatory Information .....</b>	<b>38</b>

---